

**BJE**

Model 009952 & 009953
Recommended Installation, Maintenance
and Inspection Instructions

55 Gallon Drum Alert

**DRUM
ALERT**

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS IN A READILY ACCESSIBLE LOCATION.



WARNING Never use with gasoline or highly flammable liquids.

Note: Not recommended for liquids with a specific gravity less than .85.

INSTALLATION INSTRUCTIONS

55 gallon drum applications



1. Remove rear cover.



2. Install 9-volt battery
onto circuit board.



3. Replace rear cover.



4. Flip on/off/test switch
to "test" to ensure warn-
ing lights and siren are
functioning then flip
switch to "off".



5. Tighten sensor hous-
ing to drum 3/4 NPT vent
bung. Do not over tighten
and flip on/off/test switch
to "on".

TESTING / MAINTENANCE / INSPECTION



Monthly

- Remove sensor from drum and manually raise / lower float to verify system goes into alarm mode.
- Change battery when "LOW BAT" lens lights and siren chirps.

• Follow all city, state, or federal wiring code requirements as appropriate.

• Apply city, state, or federal testing regulations as appropriate.

*ANY TEST / INSPECTION FAILURE
REQUIRES IMMEDIATE EQUIPMENT
REPLACEMENT OR REMOVAL FROM
SERVICE.*

MADE IN THE USA



ALWAYS ADHERE TO INSTALLATION / USAGE INSTRUCTIONS AND WARNINGS.

Improper use may result in injury, damage, or hazardous spill.



GENERAL WARNINGS / INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:



- Use of equipment is at individuals' own risk.

- Always abide and adhere to city, state, and federal regulations regarding use and installation of monitoring equipment.

- Always follow the product manufacturer's installation and maintenance instructions.



- Always turn off all power to alarm during maintenance activities.

- Always replace or remove from service damaged equipment immediately.



- Always report leaks / spills / accidents to appropriate authorities.



- Always wear appropriate safety equipment during maintenance and inspection activities.



- The drum contents are the sole responsibility of the drum owner.



- Never allow waste product to touch eyes or skin.



- Never install monitors outdoors without proper protection from the elements.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS IN A READILY ACCESSIBLE LOCATION.

WARRANTY

Husky Corporation will, at its option, repair, replace, or credit the purchase price of any BJE® product deemed to be defective in material and/or workmanship for a period of one (1) year.

Buyer must return the products to Husky®, transportation charges prepaid. The warranty excludes damages due to malfunction, failure to follow manufacturer's installation, operation or maintenance instructions and guidelines, unauthorized modifications or alterations, abuse, or misuse.

The warranty provisions contained herein apply only to original purchasers who use the equipment for commercial or industrial purposes. There are not other warranties of merchantability, fitness for a particular purpose, or otherwise, and any other such warranties are hereby specifically disclaimed.

Husky assumes no liability for labor charges or other costs incurred by Buyer incidental to the service, adjustment, repair, return, removal or replacement of products. Husky is not responsible for any losses (including loss of profits or revenues) incurred by the purchaser during the time necessary to repair the equipment. Husky assumes no liability for any incidental, consequential, or other damages under any warranty, express or implied, and all such liability is hereby expressly excluded.

Husky reserves the right to change or improve the design of any Husky Oil Filter Crushers, Tank Monitors, Tank Gauges, Overfill Alarms, Overfill Accessories, Air Shut-off Valves, Solenoid Valves, and Electronic Drain Valves without assuming any obligations to modify any Husky Oil Filter Crushers, Tank Monitors, Tank Gauges, Overfill Alarms, Overfill Accessories, Air Shut-off Valves, Solenoid Valves, and Electronic Drain Valves previously manufactured.