


# Bennett Pump Company

## Mechanical & Hydraulic Service Manual



### READ THIS BOOK


This book has important information for safe installation and operation of this equipment. Read and understand this book before applying power. Keep this book and tell all service personnel to read this book. If these instructions are not followed, bodily injury, death, or damage to the equipment may occur.


For new books, FAX to:  
**BENNETT MARKETING SERVICES**  
**231-799-6202**  
or visit our web page at:  
**<http://www.BennettPump.com>**


# Safety Instructions

## WARNING    ADVERTISSEMENT    ADVERTENCIA

For the safe installation of this equipment, read and understand all warning and cautions. Look for these warnings:


 **“DANGER”** means: If you do not follow the instructions, severe injury or death will occur.


 **“WARNING”** means: If you do not follow the instructions, severe injury or death can occur.


 **“CAUTION”** means: If you do not follow the instructions, damage can occur to the equipment.


 **DANGER:** Fire, explosion, injury or death will occur if fuel filters are changed by untrained personnel. Make sure only trained personnel change filter.


 **DANGER:** Gasoline is flammable. NO SMOKING OR OPEN FLAME.


 **DANGER:** Disconnect all power to this equipment and associated submerged pump (s) during installation, service or any maintenance, e.g., changing filters.


 **DANGER:** Do not use self-contained dispensers with pressurized product lines, such as above ground tanks.


 **DANGER:** The emergency cut-off valve (also called the fire valve, shear valve or impact valve) must be closed when service or maintenance is performed on this equipment.


 **WARNING:** You must have training in the service or maintenance of Bennett equipment (dispenser, pump, console, control box or submerged pump) before working on it. Maintenance and repairs must be done by authorized personnel only.

 **WARNING:** To prevent electric shock, keep the electrical parts of the dispenser dry.

 **WARNING:** Do not operate this equipment as a dispenser unless it is completely assembled.

 **WARNING:** Make sure this equipment is correctly grounded. Failure to do so can cause injury or damage equipment.

 **WARNING:** Electronic components are static sensitive. Use proper static precautions (static straps) before working on the equipment.

 **CAUTION:** Do not drill holes in fuel dispensers. Holes can cause failure of the electronic equipment and voids the UL label. The warranty will become void. Use only adhesive backed price sign mounting brackets. Order Bennett Kit KR-322.

**READ AND UNDERSTAND ALL WARNING LABELS ATTACHED TO THE DISPENSER**


## Table of Contents

|  |    |
|--|----|
| Type 75 Pumping Unit .....                 | 4  |
| Troubleshooting Self-Contained Pumps ..... | 12 |
| The Cause of Vapor Lock .....              | 21 |
| Dual Flow Solenoid Valve .....             | 26 |
| Liquid Control Meter .....                 | 32 |
| SB-100 Meter .....                         | 35 |
| Cam-AC Manual Reset .....                  | 40 |

The material included in this Service Manual is accurate at the date of publication. The intent of this manual is to assist. If further assistance is required, please contact the Bennett Technical Service Department.

**Bennett Pump Company**  
1218 E. Pontaluna Road  
Spring Lake, MI 49456  
Tech Support: 231-798-1310, Ext. 225  
Tech Support in USA: 800-423-6638  
techhelp@bennettpump.com  
www.bennettpump.com

## Type 75 Self-Contained (Suction) Pumps



## Type 75 Pumping Unit (Production 11-83 to present)

The Type 75 pumping unit is standard on all Bennett self-contained suction pumps manufactured on or after November, 1983.

### Flow of Liquid Through Pumping Unit, Air Eliminator and Meter

The Type 75 Pumping Unit moves product from the storage tank to the vehicle or container in the following manner:

1. The fuel is drawn from the storage tank through the strainer screen or filter (1). See Figure 1.
2. The rotary vane pumping unit (2) pressurizes the fluid.
3. Fuel enters the centrifugal air separator assembly (3). Any air that is present is forced out the air tube along with a small amount of liquid into the atmospheric chamber.
4. When the liquid level in the chamber lifts the float and valve assembly (4), the liquid collected in the atmospheric chamber is returned to the pump intake.
5. Air free fuel leaving the air separator opens the control valve (6) and is pumped into the meter (7). The control valve includes a built-in relief valve (8) which relieves excess pressure caused by hot weather expansion.
6. Fuel passes through the meter where it is accurately measured, then through the hose and nozzle to the vehicle or container being fueled.
7. Whenever the nozzle is not fully opened, some liquid is relieved into the pump intake through the bypass valve (9).




Figure 1 - Type 75 Schematic Flow Diagram


## Type 75 Self-Contained (Suction) Pumps

### Control Valve

The Type 75 pumping unit uses a control valve that aids in the elimination of air by producing a back pressure and is also used as a check valve for any fuel above it.

The control valve also contains a pressure relief valve. This valve ports excess hose pressure, which may result from the expansion of fuel in the hose during hot weather, to the air eliminator chamber. This action prevents hoses from bursting and helps to prevent pumping unit leaks.

The control valve of standard and heavy-duty pumping units are identical and may be interchanged. The control valve springs for the heavy-duty and standard pumping units are different and must not be interchanged.




**Figure 2 - Control Valve**

### Rotor Assembly Maintenance

Should it become necessary to service the Type 75 pumping unit's rotor, shaft assembly or blades, the rotor shaft assembly should be removed as shown using a conventional carpenter's crowbar.

1. Remove the four bolts that hold the clamping ring in place.
2. Let the clamping ring hang on the rotor cover.
3. Using the claw or hooked end of the crowbar, place the claw against the pulley as close to the shaft as possible and pry against the flange of the pump body as shown in Figure 3. Depending on the size or shape of the crowbar, it may be necessary to use a small block of wood either at the pulley or at the dome flange to provide adequate leverage.
4. Apply upward pressure on the crowbar to remove the rotor and cover.
5. It is recommended that the "O" ring, which seals the rotor cover, be replaced whenever the rotor assembly is removed from the pumping unit.
6. When reassembling the pumping unit, tap the rotor cover into position and carefully tighten the clamping ring.



**Figure 3**

## Type 75 Self-Contained (Suction) Pumps

### Lip Seal Replacement

To replace the lip seal, follow this procedure:

1. Remove the belt, pulley, and shaft key.
2. Remove the three screws that hold the seal retainer. See Figure 68. Carefully pry the old seal from the recess in the cover plate—do not scratch the shaft.
3. Wipe the shaft clean.
4. With a small plastic plug tool (furnished with new seal), slip the new seal over the shaft. Remove the tool.
5. Reinstall the seal retainer screws, key, pulley, and belt.

### Stator Removal

Should it become necessary to repair or replace the stator, remove the rotor cover and rotor shaft assembly. See Figure 68. Be careful to catch the blades when the rotor and shaft assembly is being removed. The stator, in most cases, can be slid out of the pumping unit body at this point.

In some cases, the stator may be slightly wedged in the body of the pumping unit. The filter may be removed, which will expose part of the back of the stator. Using a piece of wood and a hammer, the stator may be gently tapped out.

**NOTE: Use caution. Do not tap too hard as this will further wedge the stator in its body.**

In extreme cases, the entire pumping unit must be removed from the unit. Once the pumping unit is removed, it should be completely drained.



**DANGER: Do not use an open flame device to heat the pumping unit.**

After draining, the entire body of the pumping unit can be heated and the stator will slide out.




Figure 4

## Type 75 Self-Contained (Suction) Pumps

### Pumping Units with Throw Out Rings

All pumping units manufactured after February 1, 1989 (standard or heavy-duty) have rotors with throw out rings and carbon blades. Our studies conclude that pumping units with throw out rings produce greater vacuum and are more resistant to vapor lock.


To determine whether a dispenser has a pumping unit with the new throw out rings, look for the date code stamped directly on the pumping unit. The date code is stamped next to the filter cover. If the date code is 2P or higher, the unit has rotors with throw out rings. Any dispenser with a serial number 3P or higher uses the throw out rings.

The following part numbers can be ordered to upgrade your inventory or for a dispenser that has a vapor lock problem. Order KR042001 to receive the components listed below:

- N238301 Rotor Shaft Assembly - 1 required
- N238201 Carbon Blade - 6 required
- N650401 Throw out Ring - 2 required

*To replace blades in rotors with throw-out rings, follow this procedure:*


1. Install throw out rings in the recesses of the rotor.
2. Install the rotor in the stator assembly.
3. Rotate the rotor until a blade slot is at the 12:00 o'clock position. Install a blade.
4. Rotate the rotor 2 slots from the installed blade. Make sure the second slot is at the 12:00 o'clock position. Install a blade.
5. Repeat step 4 for the third blade.
6. Repeat steps 3 for the three remaining blades. See Figure 3.



**Figure 5**



## Type 75 Self-Contained (Suction) Pumps



## Type 75 Pumping Unit Parts List

| Item | Part Number | Description                       | Comment  |
|------|-------------|-----------------------------------|--|
| 1    | A479902     | Bolt                              | M8-1.25 X 25 mm (Use N840502 for Seal Wire Bolt)               |
| 2    | N152902     | Meter Inlet Adaptor               | With Tap   |
|      | 105588      | Meter Inlet Adaptor               | <b>High Alcohol</b>  |
| 3    | N162801     | Gasket, Meter Inlet Adaptor       |  |
| 4    | 108731      | Housing, Air Valve Float Assembly |  |
| 5    | 108737      | Gasket                            |  |
| 6    | 108732      | Shaft                             | Furnished as an Assembly - 108805                              |
| 7    | 108735      | Snap Ring                         |  |
| 8    | 108733      | Nut                               |  |
| 9    | 108734      | Float                             |  |
| 10   | 108736      | Retainer Ring                     |  |
| 11   | 110211      | ID Tag                            |  |
| 12   | N152801     | Cover, Atmospheric Chamber        | Meter Mount Style  |
|      | 105787      | Cover, Atmospheric Chamber        | Meter Mount Style - <b>High Alcohol</b>                        |
| 13   | N347901     | Cover, Atmospheric Chamber        | Pipe Outlet with Motor Mount Ears                              |
|      | 103055      | Cover, Atmospheric Chamber        | Pipe Outlet with Motor Mount Ears - <b>High Alcohol</b>        |
|      | 108945      | Cover, Atmospheric Chamber        | GPU  |
|      | 109582      | Cover, Atmospheric Chamber        | GPU - <b>High Alcohol</b>                                      |
| 14   | A471001     | Retainer Ring                     |  |
| 15   | 103089      | End Plug ( <b>Alcohol Fuel</b> )  | N225201 for Standard Fuel                                      |
| 16   | 111789      | O-Ring #O28                       | For use with 3 Piece Body - Also used with <b>High Alcohol</b> |
| 17   | N162901     | Gasket - Atmospheric Cover        |  |
| 18   | A480101     | Bolt - Round Head                 | M6-0.7 X 20 mm   |
| 19   | N888301     | Non-Reversing Float               |  |
| 20   | 111788      | O-Ring #O17                       | Also used with <b>High Alcohol</b>                             |
| 21   | 109892      | Atmospheric Float Assembly        |  |
| 22   | N162901     | Gasket - Atmospheric Cover        |  |
| 23   | N153801     | Air Separator Body                | One Piece Body - 113078  |
|      | 103051      | Air Separator Body                | One Piece Body - 113079 <b>High Alcohol</b>                    |
| 24   | N162501     | Gasket, Inlet Separator           |  |
| 25   | N162601     | Gasket, Outlet Separator          |  |
| 26   | N190201     | Insert - Air Separator Inlet      |  |
| 27   | 108727      | Tube - Air Separator              | OIML Only  |
| 28   | 108730      | Piston                            |  |
| 29   | 108725      | Spring                            |  |
| 30   | 108728      | End Cap                           |  |
| 31   | N225301     | Tube - Air Separator              |  |
| 32   | 109668      | Screw - Air Test Valve            |  |
| 33   | 109666      | Adaptor - Air Test Valve          |  |
| 34   | A019902     | Pipe Plug                         | 1/4 - 18NPT  |
| 35   | N154801     | Cover, Control Valve              |  |
|      | 103053      | Cover, Control Valve              | <b>High Alcohol</b>  |
| 36   | N162301     | Gasket                            |  |
| 37   | E008001     | Spring                            | Standard Delivery Pump 12 GPM                                  |
|      | J325201     | Spring                            | Heavy Duty Delivery Pump 22 GPM                                |
| 38   | N107301     | Control Valve Assembly            | Brass Body Version   |
|      | 113022      | Control Valve Assembly            | Aluminum Body Version with Hard Coat                           |
|      | 110368      | Control Valve Assembly            | <b>High Alcohol</b>  |
| 39   | A320901     | Pressure Relief Valve             |  |
| 40   | 111790      | O-Ring #210                       | Also used with <b>High Alcohol</b>                             |
| 41   | N150602     | Pump Body                         |  |
|      | 103052      | Pump Body                         | <b>High Alcohol</b>  |
|      | N150603     | Pump Body                         | Side Inlet Version   |
|      | 109735      | Pump Body                         | Side Inlet <b>High Alcohol</b>                                 |
| 42   | N160301     | Filter Insert                     |  |
| 43   | 100070      | Strainer                          | Standard Production  |
|      | A311901     | Filter                            | Paper Filter 35 Micron   |
|      |             | Strainer                          | Special - Used with Sack                                       |
|      | N347301     | Cloth Sack                        | 10 Micron  |

## Type 75 Pumping Unit Parts List

| Item | Part Number | Description                      | Comment  |
|------|-------------|----------------------------------|--|
| 44   | N905001     | Filter Spring                    |  |
| 45   | N162201     | Gasket                           |  |
| 46   | N154701     | Filter Cover                     |  |
|      | 103054      | Filter Cover                     | <b>High Alcohol</b>  |
| 47   | N154901     | Bypass Cover                     | Non-Adjustable   |
|      | 105585      | Bypass Cover                     | <b>High Alcohol</b>  |
| 48   | N162401     | Gasket                           |  |
| 49   | N481201     | Bypass Valve                     | Standard - Silver Spring Low Pressure  |
|      | N481202     | Bypass Valve                     | Standard - Green Spring Medium Pressure  |
|      | N481203     | Bypass Valve                     | Standard - Copper Spring High Pressure   |
| 50   | 111791      | O-Ring #229                      | Also used with <b>High Alcohol</b>   |
| 51   | A620801     | Cap Nut                          |  |
| 52   | A620901     | Seal Ring                        |  |
| 53   | N873001     | Disc                             |  |
| 54   | N872801     | Adaptor                          | Not Sold Separately - See Item #60   |
| 55   | A620101     | Retaining Ring                   |  |
| 56   | N872901     | Check Valve Body                 |  |
| 57   | N873201     | Spring                           |  |
| 58   | N873101     | Washer                           |  |
| 59   | N872701     | Shaft                            |  |
| 60   | N873301     | Check Valve Assembly             | With out Ring  |
|      | KR044102    | Check Valve Assembly             | Includes Item #50 & Item #60   |
| 61   | N308301     | Cap                              |  |
| 62   | N308201     | Adjustment Screw                 |  |
| 63   | A507901     | Washer                           |  |
| 64   | N308101     | Cover - Adjustable Bypass        |  |
| 65   | A479903     | Screw                            | M8 - 1.25 X 20 mm  |
| 66   | A000301     | Lock Washer                      |  |
| 67   | A028101     | Flat Washer                      |  |
| 68   | N106901     | Pulley - Single Groove           |  |
|      | 100040      | Pulley - Dual Groove             |  |
| 69   | N155901     | Clamping Ring                    |  |
| 70   | N162701     | Gasket                           |  |
| 71   | J682702     | Rotor Cover Assembly             |  |
| 72   | A480001     | Flat Head Screw                  |  |
| 73   | H352101     | Shaft Seal Retainer              |  |
| 74   | A323702     | Shaft Seal (with insertion tool) | 109711 Shaft Seal Kit - Includes #74 & 75 with install plug                                    |
| 75   | A247014     | Square Seal                      |  |
| 76   | N103801     | Rotor Cover                      |  |
| 77   | N650401     | Throw Out Ring                   | Standard Delivery Pump   |
|      | N238101     | Throw Out Ring                   | Heavy Duty Pump  |
| 78   | A199501     | Woodruff Key                     |  |
| 79   | A263101     | Retaining Ring                   |  |
| 80   | N238301     | Rotor & Shaft Assembly           | Standard 6 Blade Rotor   |
|      | *KR0420xx   | *Rotor Replacement Kit           | Includes #70, 74, 75, (2) 77, 80, (6) 81 <b>xx="01" Std Delivery</b><br><b>"02" Heavy Duty</b> |
| 81   | 110704      | Rotor Blade                      |  |
| 82   | N156401     | Stator                           | Standard Delivery Pump   |
|      | N159501     | Stator                           | Heavy Duty Pump  |
|      | KR036604    | Gasket Set for Pumping Unit      | Complete Set of Gaskets, Seals, and O-Rings for P/U  |

## Self Contained Troubleshooting

### General Vacuum/Pressure Information

The following components are normally associated with the pressure:

1. Control Valve
2. Meter
3. Computer or pulser drive linkage
4. Hose
5. Nozzle

The components listed below are normally associated with vacuum:

1. Blades
2. Rotor/Stator
3. Filter
4. Bypass valve and seat
5. Float (opened)
6. Installation piping
7. Tank vent pipe
8. Angle check valve or foot valve
9. Tank burial depth

Vacuum readings can change from installation to installation.

An easy method of calculating vacuum is as follows:

1. An inch of mercury is required to lift gasoline 1-1/2 feet. Divide the total lift by 1-1/2 feet to obtain vacuum.
2. An inch of mercury is required to overcome the restriction of an angle check, foot valve, or vertical check valve.
3. An inch of mercury is required to overcome the restriction of 60 feet of piping.
4. Add the readings obtained in steps 1, 2 and 3 to determine the approximate vacuum reading at fast flow.

**NOTE: Excessive vacuum indicates a restriction. Low vacuum indicates a leak.**

The following table shows normal vacuum gauge readings for a variety of lift vs. run situations.

VACUUM GAUGE READINGS  
(Inches of Mercury)

| Vertical Lift (Feet)     | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
|--------------------------|-----|-----|-----|-----|-----|-----|-----|-----|
| Horizontal Run - 0 Feet  | 3.0 | 3.6 | 4.3 | 4.9 | 5.5 | 6.1 | 6.8 | 7.4 |
| Horizontal Run - 60 Feet | 3.9 | 4.5 | 5.2 | 5.8 | 6.4 | 7.0 | 7.7 | 8.3 |

## Type 75 Self-Contained (Suction) Pumps

### How to Use Vacuum and Pressure Gauge Readings to Troubleshoot Self-Contained Dispensers

There are a variety of conditions that can contribute to no delivery or slow delivery. A pressure/vacuum gauge is an important tool in determining whether the problem is on the vacuum side or pressure side of the pump.

The vacuum gauge reading can help you determine if there are restrictions of flow in the suction piping system. It will also help you determine the ability of the pumping unit to pump.

To test the vacuum of the pump, follow this procedure:

1. Remove the pipe plug in the center of the strainer or filter cover. The cover is marked for easy identification.
2. Install the vacuum gauge.
3. Start the pump and open the nozzle to full flow for a true reading.
4. With the nozzle open, a normal vacuum reading is 6-8 inches of mercury for normal suction. See Figure 6.
5. With the nozzle closed, a normal vacuum reading is 0. See Figure 7.

To test the pressure of the pump, follow this procedure:

1. Remove the pipe plug in the center of the control valve cover. Covers are marked for easy identification.
2. Install the pressure gauge.
3. Start the pump and open the nozzle to full flow for a true reading.
4. With the nozzle open, a normal pressure reading is 16-18 pounds per square inch pressure.
5. With the nozzle closed, a normal pressure reading is 25-28 pounds per square inch pressure. See Figure 8.




Figure 6




Figure 7




Figure 8

## Type 75 Self-Contained (Suction) Pumps

The following examples are offered to help you determine the possible cause of a problem by knowing the gauge readings on the inlet (vacuum) and outlet (pressure) side of the pumping unit. Actual readings may vary slightly depending upon installation and environmental conditions.

SYMPTOM: NO FLOW

NOZZLE

OPEN

CHECK INLET


SIDE

PROBABLE CAUSES:

CONTROL VALVE STUCK SHUT  
BYPASS VALVE OPEN  
ATMOSPHERIC FLOAT VALVE OPEN  
STUCK ROTOR BLADES  
BROKEN SUCTION LINE  
STRAINER OR FILTER COMPLETELY  
PLUGGED OR IN BACKWARDS  
EMPTY TANK




AT CONTROL  
VALVE COVER



AT STRAINER  
(OR FILTER)  
COVER

## Type 75 Self-Contained (Suction) Pumps

SYMPTOM: NO FLOW




AT CONTROL  
VALVE COVER

NOZZLE OPEN


PROBABLE CAUSES:

SEIZED METER  
JAMMED COMPUTER OR GEAR BOX  
COMPLETELY RESTRICTED  
NOZZLE OR HOSE



AT STRAINER  
(OR FILTER)  
COVER

SYMPTOM: SLOW OR NO FLOW –  
PUMP LABORING




AT CONTROL  
VALVE COVER

NOZZLE OPEN  
CHECK INLET  
SIDE


PROBABLE CAUSES:

SUPPLY LINE RESTRICTION  
STUCK FOOT VALVE (IN TANK),  
ANGLE CHECK VALVE, OR  
VERTICAL CHECK VALVE  
RESTRICTED TANK VENT



AT STRAINER  
(OR FILTER)  
COVER

SYMPTOM: SLOW OR NO FLOW




AT CONTROL  
VALVE COVER

NOZZLE OPEN  
CHECK OUTLET  
SIDE

PROBABLE CAUSES:

CONTROL VALVE NOT OPENING FULLY  
PUMP VAPOR LOCKED




AT STRAINER  
(OR FILTER)  
COVER




## Type 75 Self-Contained (Suction) Pumps

SYMPTOM: SLOW FLOW




NOZZLE  
OPEN  
CHECK OUTLET  
SIDE



PROBABLE CAUSES:

PARTIALLY RESTRICTED NOZZLE OR HOSE  
BIND IN COMPUTER, GEAR BOX, METER,  
OR PULSER DRIVE LINKAGE

SYMPTOM: NO FLOW/SLOW DELIVERY




AT CONTROL  
VALVE COVER

NOZZLE  
OPEN

PROBABLE CAUSE:


TANK BURIAL TOO DEEP  
(HIGH LIFT)



AT STRAINER  
(OR FILTER)  
COVER


SYMPTOM: MOTOR LABORING, CIRCUIT  
BREAKER TRIPS OR MOTOR FAILING

NOZZLE CLOSED



AT CONTROL  
VALVE COVER

READING  
MAY VARY



AT STRAINER  
(OR FILTER)  
COVER

PROBABLE CAUSE:

BYPASS VALVE STUCK SHUT



## How to Correct Problems on Pumping Units

| PROBLEM   | CAUSE  | ACTION  |
|---|--|---|
| 1. The motor starts but the pump does not deliver fuel. | <ul style="list-style-type: none"> <li>a. The fuel supply is below the suction stub in the storage tank.</li> <li>b. The vent pipe is plugged in the storage tank.</li> <li>c. The strainer screen or filter assembly has an obstruction.</li> <li>d. The bypass valve is not seating properly due to wear or obstruction.</li> <li>e. The v-belt is loose or broken.</li> <li>f. There is an obstruction in the atmospheric float valve.</li> <li>g. The pump is out of prime.</li> <li>h. The suction line is leaking.</li> <li>i. The intake line, foot valve, angle check valve, or vertical check valve have an obstruction.</li> <li>j. The suction stub in the storage tank is on the bottom of the tank.</li> <li>k. The control valve has an obstruction.</li> <li>l. The nozzle is not working.</li> <li>m. *Two pumps are connected to one storage tank with one suction line. There is a faulty check valve in one of the supply lines.</li> </ul> | <ul style="list-style-type: none"> <li>a. Fill the storage tank.</li> <li>B. Clean the vent pipe</li> <li>c. Remove obstructions from the screen or filter assembly.</li> <li>d. Check the valve for an obstruction causing the valve to stay open, and/or replace the bypass valve.</li> <li>e. Adjust or replace the v-belt.</li> <li>f. Clean the float and valve area. Check for swelling and binding in the linkage.</li> <li>g. Check for a faulty foot valve in the storage tank or a faulty check valve in the suction line.</li> <li>h. Start the pump and open the nozzle. If bursts of air are felt while holding a finger on the vent tube, the suction line is damaged. Repair or replace.</li> <li>i. Connect a vacuum gauge to the 1/4" plug on the filter cover. Turn the pump on and open the nozzle. A reading of 15 or more inches of mercury with no flow indicates a complete blockage in the suction line. Clean the line or replace.</li> <li>j. Make sure there is a four inch clearance.</li> <li>k. Clean the control valve. It must slide freely in the valve cavity.</li> <li>l. Replace the nozzle.</li> <li>m. Disconnect the vent tube on the idle pump. Install a short copper tube. Place the end of the copper tube in a container of liquid. If the liquid is drawn out of the container when the opposite pump is operated with an open nozzle, the line check valve is faulty. Replace the check valve.</li> </ul> |
|   | *Not recommended.  |   |

## How to Correct Problems on Pumping Units

| PROBLEM                                 | CAUSE  | ACTION  |
|---|--|---|
| 2. The pump runs, but delivery is slow. | <ul style="list-style-type: none"> <li>a. The fuel supply level is low.</li> <li>b. The vent pipe is partially obstructed.</li> <li>c. The strainer screen or filter assembly has a partial obstruction.</li> <li>d. The bypass valve is not seated properly.</li> <li>e. The v-belt is loose.</li> <li>f. The voltage is too low.</li> <li>g. A blade or blades in the rotary pump will not move.</li> <li>h. An automatic nozzle has been installed.</li> <li>i. The motor is defective</li> <li>j. There is a slow leak in the suction line or intake line.</li> <li>k. The intake line, foot valve, angle or vertical check valve is partially obstructed.</li> <li>l. The control valve is partially obstructed.</li> <li>m. The nozzle check valve is sticking</li> <li>n. The hose is defective (flattened).</li> </ul> | <ul style="list-style-type: none"> <li>a. Fill the storage tank.</li> <li>b. Clean the vent pipe.</li> <li>c. Remove obstructions from the screen or filter assembly.</li> <li>d. Check the valve for an obstruction causing the valve to stay open.</li> <li>e. Adjust the v-belt.</li> <li>f. Check the power supply voltage. The dispenser uses a 115 VAC, 60 cycle electrical circuit. Check for too many pieces of equipment on one electrical line.</li> <li>g. Check the rotor and blades for damage. Replace the blades and/or rotor, if necessary.</li> <li>h. Delivery speed will be reduced by 10-25%. If maximum speed is desired, replace with a standard nozzle.</li> <li>i. Inspect the motor for loose connections. If no loose connections are found, the motor is defective. Repair or replace.</li> <li>j. Start the pump and open the nozzle. If bursts of air are felt while holding a finger on the vent tube, the suction line or intake line is damaged. Repair or replace.</li> <li>k. Connect a vacuum gauge to the 1/4" plug on the filter cover. Turn the pump on and open the nozzle. A reading of 11 to 13 inches of mercury with no flow indicates a partial obstruction in the suction line. Clean or replace the suction line components</li> <li>l. Check the valve for an obstruction. Replace if necessary.</li> <li>m. Clean or replace the nozzle check valve.</li> <li>n. Replace the hose.</li> </ul> |

## How to Correct Problems on Pumping Units

| PROBLEM  | CAUSE   | ACTION  |
|--|---|---|
| <b>3. The motor will not run.</b>  | <ul style="list-style-type: none"> <li>A. The power is off.</li> <li>b. The motor is defective.</li> </ul>  | <ul style="list-style-type: none"> <li>a. Check the circuit breaker in the station.</li> <li>b. Disconnect the power supply. Inspect the motor for loose connections. If none are found, repair or replace the motor.</li> </ul>  |
| <b>4. The dispenser does not deliver an accurate amount of product.</b>                  | <ul style="list-style-type: none"> <li>a. There is an obstruction in the control valve.</li> <li>b. There is an obstruction in the air eliminator vent tube.</li> <li>c. The meter needs calibration.</li> </ul>  | <ul style="list-style-type: none"> <li>a. Clean the control valve. It must slide freely in the valve cavity.</li> <li>b. Clean the vent tube.</li> <li>c. Check calibration test equipment for accuracy. Calibrate the meter.</li> </ul>  |
| <b>5. There is fuel running out the vent tube opening when the pump is in operation.</b> | <ul style="list-style-type: none"> <li>a. There is an obstruction in the atmospheric float valve. The valve is being held closed.</li> <li>b. The suction chamber in the pump is flooded. *(Above ground tank)</li> </ul> <p style="text-align: center;">*Not recommended.</p>  | <ul style="list-style-type: none"> <li>a. Clean the float and valve area. Make sure the float opens completely.</li> <li>b. Check the storage tank level. If it is higher than the pumping unit *(above ground tank), the condition will continue. Install Tokheim 52 valve.</li> </ul> <p style="text-align: center;">*Not recommended.</p>  |
| <b>6. The computer jumps when the pump is turned on.</b>                                 | <ul style="list-style-type: none"> <li>A. The control valve is not seated properly.</li> <li>b. There is an obstruction in the expansion relief dill valve.</li> <li>c. The gaskets are leaking.</li> <li>d. There is a worn nozzle.</li> <li>e. There is a leak in the hose.</li> <li>f. Temperature extremes cause the liquid to expand or contract.</li> </ul> | <ul style="list-style-type: none"> <li>a. Check the valve for an obstruction between the o'ring and the seat. Inspect the o'ring for damage. Replace the valve or o'ring, if needed.</li> <li>b. Check the valve by pulling the spring loaded seat. Clean any foreign matter from the valve. To install the dill valve in the control valve, use a valve tool.</li> <li>c. Replace worn gaskets.</li> <li>d. Replace the nozzle.</li> <li>e. Replace the hose.</li> <li>f. Problem will be solved when the pump begins to operate.</li> </ul> |

# The Cause of Vapor Lock

Vapor Lock is a problem that results from ambient temperatures, vapor pressure of the product and the installation. It is not a characteristic of a pump.

**Atmospheric Pressure** of 14.7 PSI (Sea Level) presses on the liquid in the tank. See Figure 1.




Figure 1

**Vapor Pressure** (the amount of pressure required to keep the product in a liquid form at 60°F) of today's product is approximately 10 PSI. See Figure 2.




Figure 2

The difference between **Atmospheric Pressure** and **Vapor Pressure** is known as the **Working Pressure**. The Working Pressure is all that the pump can create without the product turning to vapor.

$$\begin{array}{r} 14.7 \text{ PSI Atmospheric Pressure} \\ -10.0 \text{ PSI Vapor Pressure} \\ \hline 4.7 \text{ PSI Working Pressure} \end{array}$$




Figure 3

# The Cause of Vapor Lock

To measure a pump's suction, the Working Pressure must be converted to inches of vacuum. To do this, multiply the Working Pressure by 2. The result is the number of inches of vacuum that a pump can create before the product changes to a vapor. See Figure 4.




Figure 4

4.7 PSI Working Pressure = 9.4 inches of vacuum. See Figure 5.




Figure 5

## Installation is the Key

The condition of installation dictates how much suction a pump must create to pump the product.

- A. It takes 1 inch of vacuum to lift gas 1.5 feet vertically. To determine the inches of vacuum required to lift the gas in a system, follow this procedure:

Measure the distance from the top of the product in the tank to the center of the pumping unit. See Figure 6. Divide the distance by 1.5 to obtain the inches of vacuum required by the pump to lift the product.

Example: 9 feet of lift requires 6 inches of vacuum by the pump. See Figure 6.




Figure 6

# The Cause of Vapor Lock

- B. It takes 1 inch of vacuum by the pump to overcome the restriction of an angle check or foot valve. (Not part of the pump, but a necessary part of the installation.) See Figure 7.
- C. It takes 1 inch of vacuum by the pump to overcome the restriction of 60 feet of horizontal piping from the tank to the pump. See Figure 8.

To obtain the inches of vacuum to deliver product, simply add A, B and C.

A. 9 feet of lift = 6" of suction

B. Angle check or foot valve = 1" of suction

C. 60 feet horizontal run = 1" of suction

TOTAL = 8" of suction

With 9.4" of suction to work with and only 8" of vacuum required, conditions are normal and the pump delivers product without vapor locking.

Remember this condition exists when the product is at 60°F.




Figure 7




Figure 8




Figure 9

## Vapor Lock Conditions

Using the same example as above, 8" of vacuum is still required to deliver product.

With higher ambient temperatures, the vapor pressure of the product changes. As mentioned above, the Vapor Pressure of today's product is 10 PSI at 60°F. At temperatures of 90°F or higher, it can go as high as 12 PSI.




Figure 10

## The Cause of Vapor Lock

Using the same formulas as above, the Working Pressure equals Atmospheric Pressure less the Vapor Pressure.

$$\begin{array}{r} 14.7 \text{ PSI Atmospheric Pressure} \\ - 12.0 \text{ PSI Vapor Pressure of the product} \\ \hline 2.7 \text{ PSI Working Pressure} \end{array}$$




Figure 11

Multiplying the 2.7 Working Pressure by 2 equals 5.4 inches of vacuum that the pump can create before the product turns to vapor.

It still takes 8 inches of vacuum to deliver product, but with higher temperatures there is only 5.4 inches of vacuum to lift the product. **The result is Vapor Lock.**

As we have explained, the pump plays a very small part in vapor lock situations. Installation, the amount of product in the storage tank and the Vapor Pressure of the product are the main reasons for vapor lock.




Figure 12

Example: Have you ever heard of vapor lock in a diesel pump? No, because the Vapor Pressure of diesel is approximately 8 PSI.

The only real cure for vapor lock in hot climates is to keep the installation and pump cool.






Figure 13

## Remote Dispensers





# Remote Dispensers

## DUAL FLOW SOLENOID VALVE

The Dual Flow Solenoid Valve is presently used on the 7000 and 9000 Series remote and self-contained dispensers. It is mounted after the meter and its main function is to prevent product flow from an unauthorized hose when the pump motor of the same product is on. The solenoid valve is a dual function solenoid valve. One function is to control high or fast flow while the other is to control a low or dribble flow required in prepay or local preset operation. For a better understanding of the solenoid valve, consult the following flow schematic.

### Solenoid Valve Circuit Description

Product enters from the right into the inlet chamber (A) and fills the area (B) from the diaphragm orifice to the control seat. See Figure 1. The net forces on the diaphragm, (spring and pressure) are downward holding the diaphragm closed. When the solenoid coils (high and low) are energized, the plunger is pulled up, off the control seat, venting high pressure (B) fluid into the low pressure outlet chamber (C).

The fluid in high pressure chamber (A) now lifts the diaphragm against the spring and low pressure (B) fluid. Product flows directly from the inlet chamber (A) to the outlet chamber (C).

Low flow is achieved by de-energizing the high flow coil. This allows the bottom half of the plunger to fall, partially restricting flow through the control seat. Pressure at area B rises causing the diaphragm (high flow) to close. Low flow is directed through the diaphragm orifice, then through a .093 diameter drilled hole in the high flow plunger into the outlet chamber (C). When power to the low flow coil is cut, the top plunger drops against the low flow seat and all flow stops.






Figure 1

## Meters



## Remote Dispensers

### LIQUID CONTROL M5A1 METER

Bennett Pump Company uses Liquid Control Systems' M5A1 meter in its 7800 High Capacity Series. The M5A1 meter allows the accurate measurement of motor fuel when delivering up to 60 GPM. The meter is calibrated at the factory using a solvent for safety purposes. The meter must be checked and recalibrated, if necessary, at the time of installation. After the initial installation, Bennett recommends follow-up checks at 90 and 180 days to insure accurate measurement. After the break-in period, semi-annual calibration checks are all that is required. Following is the procedure to calibrate the M5A1 meter.

#### How to Calibrate the Meter

*To gain access to the meter, follow this procedure:*

1. Use the Bennett 001 key to remove the lower door (1) on the junction box side of the dispenser. See Figure 2. Set the doors aside in a protected area to avoid damage.
2. Remove the two screws (2) that hold the nozzle boot cover to the frame. See Figure 2. Remove the cover and set aside.
3. Cut and remove the meter seal wire (1). See Figure 3.
4. Remove the four screws (2) holding the adjuster housing cover (3). See Figure 3. Remove the cover.




Figure 2

*To calibrate the meter, follow this procedure:*

1. Dispense 50 or 100 gallons (200 or 400 liters) of fuel into an official test measure to determine the amount of adjustment necessary.

**NOTE: A minimum of a 50 gallon test measurement must be used.**

2. Read the setting on the calibration adjuster. The amount of error is added to or subtracted from this reading. If an adjustment in calibration is required, loosen the screw (1) holding the clamp on the adjuster. See Figure 96.
3. Turn the adjuster thimble (2) IN (top of thimble moves away from you) on the adjuster barrel to decrease the amount delivered. Turn the thimble OUT (top of the thimble moves towards you) on the adjuster barrel to increase the amount delivered. See Figure 4.

**NOTE: One complete turn of the thimble is equal to 1 gallon in 100 gallons or 1% of delivered volume. The adjuster is graduated in divisions of 1%, 0.1% and 0.02%.**




Figure 3




Figure 4

## Remote Dispensers

4. Dispense 50 or 100 gallons (200 or 400 liters) of fuel to allow the meter to adjust to the new setting. Do not make any adjustments based on this delivery.
5. Make sure the meter is properly calibrated. Dispense another 50 or 100 gallons (200 or 400 liters) of fuel into an official test measure to check the calibration.
6. After resetting the calibration adjuster, tighten the clamp to hold the adjustment. See Figure 5.




Figure 5

**NOTE:** Always make the final adjustment by turning **IN** on the thimble. If the new setting is a higher number than the original, turn beyond the desired figure and come back to it.

The following example will help explain the calibration:

Assume the adjuster setting at the start of the test read 2.05. Product was dispensed until the dispenser registered 100 gallons. The official test measure or prover registered 98.7 gallons or 1.3 gallons short. Add the 1.3 gallon reading to the beginning adjuster reading to get the new setting.

Beginning Adjuster Reading 2.05  
+ Amount Short in Prover 1.30


New setting on Adjuster = 3.35

Another test through the meter should then show 100 gallons both on the dispenser volume window and the official test measure or prover.

For test volumes other than 100 gallons, the following formula applies:

|                   |                         |   |                              |
|-------------------|-------------------------|---|------------------------------|
| Divide the result | Gallons on Prover minus | = | Adjuster Percent to increase |
| By this Amt.      | Gallons on Dispenser    |   | or decrease prover volume    |

## Remote Dispensers



| Ref. No. | Part No.   | Description                     | 7811 | 7812 | 7822 |
|----------|------------|---------------------------------|------|------|------|
| 1        | N778701    | Bracket, Totalizer              | 1    | 2    | 2    |
| 2        | A533101    | Clamp, Cable                    | 1    | 2    | 2    |
| 3        | N748101    | Cover, Gear Plate               | 1    | 2    | 2    |
| 4        | N748401    | Cover & Conduit Assembly-Pulser | 1    | 2    | 2    |
| 5        | N747201    | Gear Plate Assembly             | 1    | 2    | 2    |
| 6        | J794701    | Nut, Conduit                    | 1    | 2    | 2    |
| 7        | J771501    | Nut, Conduit                    | 1    | 2    | 2    |
| 8        | A219010    | Nut, 1/4-20                     | 4    | 8    | 8    |
| 9        | A219004    | Nut & Washer                    | 2    | 2    | 2    |
| 10       | N237903    | Pulser Assembly                 | 1    | 2    | 2    |
| 11       | N746401    | Retainer, Gear Plate            | 1    | 2    | 2    |
| 12       | A228502    | Rivet, Pop                      | 2    | 4    | 4    |
| 13       | A099001    | Screw                           | 1    | 2    | 2    |
| 14       | A188601    | Screw                           | 2    | 4    | 4    |
| 15       | A277601    | Screw, 10-24x3/4                | 4    | 8    | 8    |
| 16       | A397202    | Screw, Flat head                | 4    | 8    | 8    |
| 17       | N749201    | Screw, Special                  | 2    | 4    | 4    |
| 18       | 132X100101 | Seal Wire                       | 1    | 2    | 2    |
| 19       | 132X100102 | Seal Wire                       | 1    | 2    | 2    |
| 20       | A585001    | Standoff                        | 3    | 6    | 6    |
| 21       | N789401    | Support Strap, Cable            | —    | —    | 1    |
| 22       | N780901    | Totalizer & Cable Assembly      | 1    | 2    | 1    |
|          | N780908    | Totalizer & Cable Assembly      | —    | —    | 1    |
| 23       | J992813    | Cable Assembly, 14.13           | 1    | 2    | 1    |
|          | J992817    | Cable Assembly, 31.88           | —    | —    | 1    |
| 24       | A294701    | Pin                             | 1    | 2    | 1    |
| 25       | A584101    | Totalizer (Counter)             | 1    | 2    | 1    |

## Remote Dispensers

### **SB-100 METER**

The SB-100 Meter was introduced in Bennett's 3900 and 4000 Series in the last quarter of 1991. The introduction of the meter in other models began in the first quarter of 1992. The SB-100 meter is a precision device built to maintain .3% accuracy for flow rates from 1.5 GPM (5 LPM) to 26 GPM (100 LPM). The SB-100 is a volumetric meter employing four pistons with seals and associated chambers. During the first year of use, the SB-100 meter's calibration should be checked upon installation, after 90 days and after 180 days in order to insure accurate measurement. After the break-in period, semi-annual calibration checks are all that is required.

*To check the calibration of the SB-100 meter, perform the following:*

1. Fill an official test measure with fuel to wet its interior. Return the fuel to the proper storage tank and drain the test measure for 10 seconds. Failure to drain the test measure for 10 seconds may cause different calibration readings.
2. Dispense five gallons of fuel at full flow into the official test measure. If calibration readings are within the local Weights and Measures tolerance, return the fuel to its proper storage tank and perform the required slow flow test.


The slow flow test is performed when the latch on the nozzle is at its lowest setting or at five gallons per minute, whichever is least. The slow flow calibration readings must be within tolerance to the fast flow calibration readings as well as to the zero reading of the official test measure. Failure to maintain the above tolerance during the slow flow test indicates a defective meter which must be replaced. Calibration adjustment will not alter tolerances between slow flow and fast flow test.

### **SB-100 METER - FIELD CALIBRATION**


Each SB-100 meter is provided with the following calibration information.

- The dial adjusting cover has (+) and (-) arrows to indicate the correct direction to rotate the dial to either increase or decrease delivery.
- A self-adhesive metal label listing the minimum incremental adjustment is attached to the collector housing immediately above the adjusting dial.


These provisions were made to assist the service person in making a quick and accurate change to the meter's calibration.



**Figure 6**



**Figure 7**




**Figure 8**

## Remote Dispensers


The dial cover has two pin hubs, one to the left of the shaft and one to the right. The seal pin may be inserted in either hub. See Figure 9. The smallest adjustment (.6 cu. in.) occurs when the pin is pulled from one side and inserted in the other side by moving the dial the least amount or half a hole. A 1.2 cu. in. adjustment is made by pulling the pin and turning the dial until the next adjacent hole aligns with the same hub and re-inserting the pin.

*To calibrate the meter, follow this procedure:*

1. Measure the actual delivery of the meter at fast flow in an accurate test measure.
2. Cut and remove the existing seal wire and remove the seal pin. See Figure 10.
3. Turn the dial the necessary amount in the (+) or (-) direction to increase or decrease the quantity of fuel delivered.
4. Re-insert the seal pin in the desired pin hub.
5. Test calibration at the new setting by dispensing five gallons (20 liters) of fuel to allow the meter to adjust to the new settings. Do not make any adjustments based on this delivery.
6. Make sure the meter is properly calibrated. Dispense another five gallons (20 liters) of fuel into an official test measure to check the calibration and make adjustments, if necessary.
7. Reseal the meter adjustment.



**Figure 9**



**Figure 10**

### Example 1

1. A fast flow test at 11 GPM shows a +3 cu. in. reading in a five gallon test measure.
2. Remove the existing seal and pin and turn the dial clockwise (-) 5 minimum adjustments (half holes) and reinsert the pin.

$$\frac{3 \text{ cu. in.}}{6 \text{ cu. in./adjustment}} = 5 \text{ half holes (-) CW}$$

3. Test and reseal.

### Example 2

1. A fast flow test at 25 GPM shows a -2 cu. in. reading in a five gallon test measure.
2. Remove the existing seal and pin and turn the dial counterclockwise (+) 3 minimum adjustments (half holes) and reinsert the pin.

$$\frac{2 \text{ cu. in.}}{6 \text{ cu. in./adjustment}} = 3.333 = 3 \text{ half holes (+) CCW}$$

3. Test and reseal.

## Remote Dispensers

### SB-100 Flow Schematic

1. Product enters at the bottom inlet (1) and fills the inner cavity of the meter. See Figure 11.
2. As the meter body fills, product passes around the crankshaft and up to the top throat of the meter body. From the top throat, product flows to the distributor (2) which either ports product "to" or "from" each of the four piston chambers.
3. When the distributor (2) is in a position that allows product to be ported "to" a piston chamber (3), equal pressure is applied across both sides of the piston. Equal pressure applied across a piston offers zero resistance to the crankshaft (5) via the piston's connecting rod (6).
4. When the distributor (2) is in a position that allows product to be ported "from" a piston chamber (4), there is greater product pressure applied to the inside of the piston than to its outer side. The differential of pressure causes the piston to travel in an outward direction. As the piston travels in an outward direction, product is ported to the meter's top collector and to its outlet.
5. As a piston is forced in its outward direction, a rotational force is applied to the crankshaft via the piston's connecting rod. This rotational force of the crankshaft is then applied to adjacent pistons, which offering zero resistance, allows them to be pulled in their inner direction easily. This allows product from the distributor to fill the piston chamber. The above process is repeated by all four pistons.
6. A spring and pressurized countervalue (7) employing a diaphragm imparts a downward thrust on the rotating distributor to seal its surfaces and prevent internal leakages which would result in unmeasured product being delivered.




Figure 11




## Remote Dispensers

| PROBLEM  | CAUSE   | SOLUTION   |
|--|---|--|
| 1. Over delivery and out of tolerance difference between fast and slow delivery. | a. Dirty or gummed pistons and/or piston chambers.<br><br>b. Damage or worn piston seals. | a. Remove cylinder covers. Remove screw holding piston to connecting rod. Using vise grips, secure the center hub of the piston and pull straight out. Clean piston seal and piston chamber using mineral spirits. Reassemble in reverse order.<br><br>b. Replace all pistons. |

**NOTE:** To install piston in piston chamber, the piston must be rotated 90 degrees and the seal depressed with thumb and forefinger. Install the piston into the chamber. Rotate the piston back 90 degrees and install the screw that connects the piston to the connecting rod. See Figure 12.


**CAUTION:** When the piston is removed from the chamber, use extreme caution so that the connecting rods do not scratch the cylinder or chamber sleeves. When the piston is re-installed or a new piston is installed, extreme caution must be used to prevent damage to the piston seal.




**Figure 12**

| PROBLEM  | CAUSE  | SOLUTION  |
|--|--|---|
| 2. Leakage between meter shaft and collector body.   | a. Top lip seal is damaged   | a. Replace top lip seal.  |
| 3. Internal leakage between the distributor and top countervale assembly or bottom valve plate resulting in over delivery. | a. Damaged counter valve assembly distributor, and countervales.<br><br><b>NOTE:</b> Replace all items to insure proper mating surfaces. | a. Replace counter valve assembly, distributor, and countervales.<br><br>See Figure on next page.<br>1 Remove coupling half.<br><br>2 Remove lip seal retainer<br>3 Remove lip seal<br>4 Remove four screws holding collector body<br>5 Remove collector body<br>6 Remove six screws holding retainer to bottom of collector body<br>7 Remove retainer<br>8 Remove and replace countervale assembly<br>9 Remove and replace distributor |

# SB100 Electronic Meter



# SB100 Mechanical Meter



## SB100 Meter Parts List

| Item | Part Number | Description                         | Comment   |
|------|-------------|-------------------------------------|---|
| 1    | N/A         | Lead Seal Wire                      | Please Call 231-798-1310 for details                  |
| 2    | N/A         | Universal Link                      | Please Call 231-798-1310 for details                  |
| 3    | H651203     | Half Coupling                       | Unthreaded <b>See Kit List</b>                        |
| 4    | H650402     | Half Coupling                       | Threaded  |
| 5    | H650501     | Screw                               |   |
| 6    | A480001     | Screw, Flat Head                    | M3.5 - 0.6 X 8 mm                                     |
| 7    | N666401     | Shaft Seal Retainer                 |   |
| 8    | 107694S     | Shaft Seal                          |   |
| 9    | A586901     | Screw, Hex Head                     | M6 - 1.0 X 20 mm                                      |
| 9    | N840401     | Screw, Hex Head                     | M6 - 1.0 X 20 mm with Seal Hole                       |
| 10   | A247018     | O-Ring, Square Section              |   |
| 11   | N646502     | Collector Cover                     |   |
| 11   | 103044      | Collector Cover                     | <b>High Alcohol</b>                                   |
| 12   | A247019     | O-Ring, Square Section              |   |
| 13   | N673201     | Gasket                              |   |
| 14   | 103077      | Spring                              |   |
| 15   | A631901     | Screw, Fil Head                     | M4 - 0.7 X 10 mm Stainless Steel                      |
| 16   | N685901     | Inner Diaphragm Retainer            |   |
| 17   | 100081      | Diaphragm                           |   |
| 18   | N673101     | Gasket                              |   |
| 19   | N902501     | Counter Valve                       |   |
| 20   | 101183      | Counter Valve Assembly              |   |
| 21   | N685801     | Outer Diaphragm Retainer            |   |
| 22   | A586801     | Screw, Pan Head                     | M5 - 0.8 X 12 mm                                      |
| 23   | 101184      | Collector Cover Assembly            |   |
| 23   | 103048      | Collector Cover Assembly            | <b>High Alcohol</b>                                   |
| 24   | N672601     | Drive Pin                           |   |
| 25   | N891601     | Distributor                         |   |
| 26   | A579901     | Retaining Ring                      |   |
| 27   | A584001     | Washer                              | Crankshaft Support                                    |
| 28   | 101185      | Meter Body Assembly                 |   |
| 28   | 103049      | Meter Body Assembly                 | <b>High Alcohol</b>                                   |
| 29   | N903701     | Roller & Bearing Assembly           |   |
| 30   | A631801     | Washer                              |   |
| 31   | A239401     | Lock Nut                            |   |
| 32   | N903801     | Crank Shaft Assembly                | Gallons   |
| 32   | N903802     | Crank Shaft Assembly                | Liters  |
| 33   | N659201     | Cylinder Cover                      |   |
| 33   | 103041      | Cylinder Cover                      | <b>High Alcohol</b>                                   |
| 34   | A247010     | O-Ring, Square Section              |   |
| 35   | N792201     | Piston Screw, Hex Head              | With Nylon Patch (also use with <b>High Alcohol</b> ) |
| 36   | N701502     | Piston Assembly                     |   |
| 36   | 103046      | Piston Assembly                     | <b>High Alcohol</b>                                   |
| 37   | N654802     | Connecting Rod                      | Lower Rod   |
| 38   | N654801     | Connecting Rod                      | Upper Rod   |
| 39   | A586401     | Retaining Ring                      |   |
| 40   | N683701     | Calibrating Cover                   |   |
| 40   | 103043      | Calibrating Cover                   | <b>High Alcohol</b>                                   |
| 41   | 111787      | O-Ring                              | Also used with <b>High Alcohol</b>                    |
| 42   | N701601     | Calibrating Dial & Screw Assembly   |   |
| 43   | N675801     | Seal Pin                            |   |
| 44   | N779601     | Calibration Cover Assembly          |   |
| 44   | 103047      | Calibration Cover Assembly          | <b>High Alcohol</b>                                   |
| 45   | 100535      | Gasket, Meter Inlet                 | Not Shown   |
| 46   | N902401S    | Valve Plate                         | Not Shown   |
| 47   | A586601     | Screw, Valve Plate                  | Not Shown   |
| 48   | A578404     | DU Bearing, Meter Body              | Not Shown, for meters built since 1995                |
| 49   | N906501     | DU Bearing and Retainer, Meter Body | Not Shown, for meters built before 1995               |

## Kit List

| Part Number | Description                                      | Comment   |
|-------------|--|---|
| 100965      | Kit, SB100, V'Plate/C'Valve Replacement          | Includes 1 each of items 8, 10, 12, 13, 14, 20, 25 & 46               |
| KR043601    | Kit, SB-100 Piston Retail, 4 Per                 | Includes 4 of items 34, 35, & 36, 1 each of 10 & 45                   |
| 112343      | Kit, SB-100 Piston Retail, <b>Alcohol</b> Meters | Includes 4 of items 34, 35, & 36, 1 each of 10 & 45                   |
| 107170      | Kit, Crankshaft Bearing Replacement              | Includes 2 of item 29, 1 ea. of 10, 31 & 45                           |
| 112246      | Kit, Lower Hydraulic Gallon SB-100               | Includes 4 of items 34, 35, & 36, 1 ea. of 8, 10, 12, 26, 32, 45 & 48 |
| 112347      | Kit Lower Hydraulic Gallon SB-100 <b>Alcohol</b> | Includes 4 of items 34, 35, & 36, 1 ea. of 8, 10, 12, 26, 32, 45 & 48 |
| 112247      | Kit Lower Hydraulic Liter SB-100                 | Includes 4 of items 34, 35, & 36, 1 ea. of 8, 10, 12, 26, 32, 45 & 48 |
| 112348      | Kit Lower Hydraulic Liter SB-100 <b>Alcohol</b>  | Includes 4 of items 34, 35, & 36, 1 ea. of 8, 10, 12, 26, 32, 45 & 48 |
| KR044601    | Kit, SB-100 Diaphragm/Distributor                | Includes 4 of item 15, 1 ea. of 8, 10, 12, 13, 14, 17, 25 & 45        |
| 112651      | Kit, SB-100 Meter Coupling                       | Includes items 3, 4 & 5   |
| 103490      | Kit, Tools for Du Bearing Replacement            |   |
| 112248      | Field Du Bearing Install/Removal Tool            |   |


These two kits are for SB100 meters built since 1995

|          |  |  |
|----------|--|--|
| KR044703 | Kit, SB-100 Meter, Crankshaft, Gallons | Includes 4 of item 34, 1 ea. of 8, 10, 12, 26, 32, 45 & 48 |
| KR044704 | Kit, SB-100 Meter, Crankshaft, Liters  | Includes 4 of item 34, 1 ea. of 8, 10, 12, 26, 32, 45 & 48 |

These two kits are for SB100 meters built before 1995

|          |  |  |
|----------|--|--|
| KR044701 | Kit, SB-100 Meter, Crankshaft, Gallons | Includes 4 of item 34, 1 ea. of 8, 10, 12, 26, 32, 45 & 49 |
| KR044702 | Kit, SB-100 Meter, Crankshaft, Liters  | Includes 4 of item 34, 1 ea. of 8, 10, 12, 26, 32, 45 & 49 |

## Cam-AC Manual Reset Mechanism



## Cam-AC Manual Reset Mechanism

### Servicing the Cam-AC Operating Mechanism and Motor Switch

The Cam-AC handle assembly is used with Veeder-Root computers equipped with a mechanical reset. The computer is reset by a separate reset mechanism that is part of the computer. The reset mechanism is activated by a small lever located next to the operating handle.

The Cam-AC assembly was designed to alleviate computer and linkage damage due to activating the handle if the computer was not reset. This is accomplished by the use of a “clutch” which disengages if the computer exerts more pressure than a spring in the Cam-AC assembly. If the computer is reset, there is more pressure exerted by the Cam-AC spring than the computer thus allowing the handle to activate the computer and a pump motor switch.

### Operation

Once the computer is reset, turning the handle (1) clockwise rotates the shaft (2), engages the clutch (3-5), and rotates the universal link (6). The clockwise rotation of the universal link activates the computer to its ON position. At the same time, the cam lobe of the clutch half (5) rotates to its smaller diameter side. This allows the switch shaft (9) to be in its down position which activates the motor switch to its ON position. See Figure 1.

If the computer is not reset, turning the handle clockwise forces the computer to exert greater pressure on the clutch half (5) than the spring (4) forces on clutch half. This forces the clutch halves apart preventing the universal link from rotating and trying to activate the computer. The above action prevents damage to the computer as well as the universal link.

When the handle is turned to its OFF position, the clutch stays engaged which rotates the universal link in a counter clockwise position. This locks out the computer until it is reset again. At the same time, clutch half (5) rotates to the position that its large diameter side forces the switch shaft to its UP position. This action opens the switch and shuts off the pump motor.




Figure 1

## Cam-AC Manual Reset Mechanism

### Computer Reset

**Motor Switch ON Position.** See Figure 2.

The linkage connecting the switch actuating mechanism to the computer should be adjusted so the pump motor does not turn on until the reset latch pawl (A) fully engages the deep notch in the shaft cam (B). This makes certain that the computer reset mechanism is in proper position to function when released by the trip lever next to the operating handle.

**Motor Switch OFF Position.** See Figure 3.

The operating linkage must be adjusted so the motor turns off after pawl (C) engages notch (D) of shaft cam (B). This happens before second notch (E) is engaged. This assures proper function of the interlock mechanism. Also, the stop adjustment should be set so approximately 1/8" overtravel is allowed after pawl (C) engages third notch (F).


Make sure that all rods or connecting links attached to the computer are free and do not exert thrust against the computer or introduce binds when being operated.

### **Maintenance**


Lubricate all points marked "A" in Figure 1 with a light weight engine oil twice a year.

The Cam-AC assembly does not require adjustment. If a failure occurs, the individual part of the assembly may be replaced.

**NOTE: Due to non-interchangeable improvements, be certain to specify model and specification numbers when ordering replacement parts.**



**Figure 2**



**Figure 3**



## Cam-AC Manual Reset Mechanism

### Switch Adjustment



**DANGER:** To prevent personal injury and/or equipment damage, all power must be removed from the pump or dispenser before adjusting the switch.

To adjust the motor switch, remove the junction box cover of the Cam-Ac assembly. Using a continuity tester across the terminals of the switch, rotate the switch cam follower to the position where the operating handle operates the switch as shown in Figure 4.

**NOTE:** Before rotating the cam follower, the jam nut must be loosened. When proper switch adjustment is complete, tighten the jam nut securely.




Figure 4

# Cam-AC Manual Reset Mechanism

## WIRING DIAGRAMS

### SELF-CONTAINED MODELS 3700, 3900, 4000, AND 4100 SERIES WITH CAM-AC (MECHANICAL RESETS)

NOTE: INDICATES FIELD CONNECTIONS  
 INDICATES MANUFACTURER'S CONNECTION.  
 FOR BALLAST WIRING DIAGRAM SEE INSIDE OF BALLAST BOX.

IF MOTOR IS TO BE CONNECTED TO A 230 VOLT SUPPLY LINE AND NO SEPARATE GROUND IS FURNISHED FOR THE SOLENOIDS, USE 230 VOLT SOLENOID, CODE 292.




Figure 5 - Wiring for Cam-AC

## 01/06



