

Education Safety

IJ Submersible Pumps



- 1. Never attempt to raise pump by its electrical cord.
- 2. Always use a Gorman-Rupp approved control box, mounted in a vertical position.
- 3. Always check rotation on 3 phase pumps.
- 4. Shut down and lock out all related electrical circuits before performing any maintenance.
- $5. \ \ Do \ not \ hold \ reset \ button \ if \ overload \ control \ trips \ off. \ Wait \ 10 \ minutes \ before \ resetting \ again.$
- 6. Never put pump directly on soft, loose bottom.
- 7. Be sure to connect pump to correct phase and voltage.
- 8. Do not run pump if voltage is not within limits.
- 9. Check oil level only when pump has cooled to air temperature.
- 10. Use only recommended transformer oil.